

TAKPAVE TACTILE SURFACES

INSTALLATION INSTRUCTIONS



Having carried out any essential repairs to damaged surfaces and/or major voids, proceed with the following sequence:-

1. Thoroughly clean (and for concrete, if necessary Shot Blast) the laying area and remove any loose material.
NOTE: Only prepare surface area sufficient for that day's installation.
Ensure surface is as dry as possible. Do not apply in the rain.
2. Mark out path for exact width of tile.
3. Thoroughly wipe underside of each tile, using the primer provided, with a clean cloth.
Allow 3 to 4 minutes for tile to dry. Protective neoprene gloves must be used for this application.
NOTE: Do not stack tiles to dry or at any time when primed.
4. Empty Hardener (B) into Polyurethane Resin (A) container, and then thoroughly mix for several minutes with a metal rod. Ensure even colour mix throughout container.
5. Apply mixed adhesive to pre-marked area then carefully and evenly spread adhesive, using a spreading comb. Typical coverage for one container equates to 5 tiles.
NOTE: Do not spread adhesive beyond the surface width.
6. Within 20 minutes of mixing and applying adhesive, carefully place pre-primed tile onto adhesive sliding the tile into position and apply even pressure from centre of tile outwards.
NOTE: Take care in positioning first tile correctly in order that subsequent tiles butt and form a straight path, forming correct pattern match.

Under certain conditions it may be necessary to apply weights to the tiles to ensure the edges do not lift.
7. Typical 'Walk on' time is 6 hours after installing provided temperatures are not below 20°C (68 °F). At lower temperatures this time will be extended.